



Network Storage 806 Series
Quick Start Guide

Legal Information

About this Document

- This Document includes instructions for using and managing the Product. Pictures, charts, images and all other information hereinafter are for description and explanation only.
- The information contained in the Document is subject to change, without notice, due to firmware updates or other reasons. Please find the latest version of the Document at the Hikvision website (<https://www.hikvision.com>). Unless otherwise agreed, Hangzhou Hikvision Digital Technology Co., Ltd. or its affiliates (hereinafter referred to as "Hikvision") makes no warranties, express or implied.
- Please use the Document with the guidance and assistance of professionals trained in supporting the Product.

About this Product

This product can only enjoy the after-sales service support in the country or region where the purchase is made.

Acknowledgment of Intellectual Property Rights

- Hikvision owns the copyrights and/or patents related to the technology embodied in the Products described in this Document, which may include licenses obtained from third parties.
- Any part of the Document, including text, pictures, graphics, etc., belongs to Hikvision. No part of this Document may be excerpted, copied, translated, or modified in whole or in part by any means without written permission.
- **HIKVISION** and other Hikvision's trademarks and logos are the properties of Hikvision in various jurisdictions.
- Other trademarks and logos mentioned are the properties of their respective owners.
- **HDMI**[™] The terms HDMI and HDMI High-Definition Multimedia Interface, and the HDMI Logo are trademarks or registered trademarks of HDMI Licensing Administrator, Inc. in the United States and other countries.

LEGAL DISCLAIMER

- TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW, THIS DOCUMENT AND THE PRODUCT DESCRIBED, WITH ITS HARDWARE, SOFTWARE AND FIRMWARE, ARE PROVIDED "AS IS" AND "WITH ALL FAULTS AND ERRORS". HIKVISION MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, MERCHANTABILITY, SATISFACTORY QUALITY, OR FITNESS FOR A PARTICULAR PURPOSE. THE USE OF THE PRODUCT BY YOU IS AT YOUR OWN RISK. IN NO EVENT WILL HIKVISION BE LIABLE TO YOU FOR ANY SPECIAL, CONSEQUENTIAL,

INCIDENTAL, OR INDIRECT DAMAGES, INCLUDING, AMONG OTHERS, DAMAGES FOR LOSS OF BUSINESS PROFITS, BUSINESS INTERRUPTION, OR LOSS OF DATA, CORRUPTION OF SYSTEMS, OR LOSS OF DOCUMENTATION, WHETHER BASED ON BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY, OR OTHERWISE, IN CONNECTION WITH THE USE OF THE PRODUCT, EVEN IF HIKVISION HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES OR LOSS.

- YOU ACKNOWLEDGE THAT THE NATURE OF THE INTERNET PROVIDES FOR INHERENT SECURITY RISKS, AND HIKVISION SHALL NOT TAKE ANY RESPONSIBILITIES FOR ABNORMAL OPERATION, PRIVACY LEAKAGE OR OTHER DAMAGES RESULTING FROM CYBER-ATTACK, HACKER ATTACK, VIRUS INFECTION, OR OTHER INTERNET SECURITY RISKS; HOWEVER, HIKVISION WILL PROVIDE TIMELY TECHNICAL SUPPORT IF REQUIRED.
- YOU AGREE TO USE THIS PRODUCT IN COMPLIANCE WITH ALL APPLICABLE LAWS, AND YOU ARE SOLELY RESPONSIBLE FOR ENSURING THAT YOUR USE CONFORMS TO THE APPLICABLE LAW. ESPECIALLY, YOU ARE RESPONSIBLE, FOR USING THIS PRODUCT IN A MANNER THAT DOES NOT INFRINGE ON THE RIGHTS OF THIRD PARTIES, INCLUDING WITHOUT LIMITATION, RIGHTS OF PUBLICITY, INTELLECTUAL PROPERTY RIGHTS, OR DATA PROTECTION AND OTHER PRIVACY RIGHTS. YOU SHALL NOT USE THIS PRODUCT FOR ANY PROHIBITED END-USES, INCLUDING THE DEVELOPMENT OR PRODUCTION OF WEAPONS OF MASS DESTRUCTION, THE DEVELOPMENT OR PRODUCTION OF CHEMICAL OR BIOLOGICAL WEAPONS, ANY ACTIVITIES IN THE CONTEXT RELATED TO ANY NUCLEAR EXPLOSIVE OR UNSAFE NUCLEAR FUEL-CYCLE, OR IN SUPPORT OF HUMAN RIGHTS ABUSES.
- IN THE EVENT OF ANY CONFLICTS BETWEEN THIS DOCUMENT AND THE APPLICABLE LAW, THE LATTER PREVAILS.
- **© Hangzhou Hikvision Digital Technology Co., Ltd. All rights reserved.**

Preface




Applicable Models

This manual is applicable to the models listed in the following table.

Series	Model
DS-A80600S-I	DS-A80624SI
	DS-A80636SI
	DS-A80648SI
	DS-A80660SI

Symbol Conventions

The symbols that may be found in this document are defined as follows.



Symbol	Description
 Note	Provides additional information to emphasize or supplement important points of the main text.
 Caution	Indicates a potentially hazardous situation, which if not avoided, could result in equipment damage, data loss, performance degradation, or unexpected results.
 Danger	Indicates a hazard with a high level of risk, which if not avoided, will result in death or serious injury.

Safety Instructions

- Proper configuration of all passwords and other security settings is the responsibility of the installer and/or end-user.
- In the use of the product, you must be in strict compliance with the electrical safety regulations of the nation and region. Please refer to technical specifications for detailed information.
- Input voltage should meet both the SELV (Safety Extra Low Voltage) and the Limited Power Source with 100 to 240 VAC or 12 VDC according to the IEC60950-1 standard. Please refer to technical specifications for detailed information.
- Do not connect several devices to one power adapter as adapter overload may cause overheating or a fire hazard.
- Please make sure that the plug is firmly connected to the power socket.

- If smoke, odor or noise rise from the device, turn off the power at once and unplug the power cable, and then please contact the service center.

The elements of the **instructional safeguard** shall be as follows:

- element 1a: , IEC 60417-6042 (2010-11); and
, IEC 60417-6172 (2012-09)
- element 2: “Caution” or equivalent word or text, and “Shock hazard” or equivalent text
- element 3: optional
- element 4: “Disconnect all power sources” or equivalent text

The elements of the **instructional safeguard** shall be as follows:



- element 1a:  IEC 60417-6056 (2011-05) for moving fan blades; or
 IEC 60417-6057 (2011-05) for other moving parts
- element 2: “Moving parts” or “Moving fan blade” as applicable, or equivalent text
- element 3: optional
- element 4: “Keep body parts away from moving parts” or “Keep body parts away from fan blades” or “Keep body parts out of the motion path” as applicable, or equivalent text

Table of Contents

Chapter 1 Equipment Installation	1
1.1 Check the Packing List	1
1.2 Product Appearance Introduction	1
1.2.1 Front panel	1
1.2.2 Rear panel	3
1.3 Installation.....	6
Chapter 2 System Configuration	8
2.1 Login and Activation.....	8
2.2 Configuration Wizard	10
Chapter 3 Service Configuration	14
3.1 Add Channel	14
3.2 Configure Storage Pool	15
3.2.1 Add Storage Pool.....	15
3.2.2 Edit/Delete Storage Pool.....	16
3.2.3 Adjust Storage Pool Space	17
3.2.4 Link Channel	17
3.3 Configure Recording Schedule	18
3.4 Live View	21

Chapter 1 Equipment Installation

1.1 Check the Packing List

Please check the packing list to ensure that all items are complete.

1.2 Product Appearance Introduction

1.2.1 Front panel

The front panels of the 24-slot and 36-slot / 48-slot / 60-slot devices are shown in Figure 1-1 and Figure 1-2 respectively. The order of the HDD positions is on the left side of the chassis.







Figure 1-1 Front Panel of 24-Slot Device








Figure 1-2 Front Panel of 36-Slot / 48-Slot / 60-Slot Device

Please refer to Table 1-1 for the description of the buttons and indicators.

Table 1-1 Button and Indicator Description

Icon	Name	Description
	Power button and indicator	Green light solid on: The device is on, and the power supply is working normally. Long press for 4 seconds: Shutdown. Long press for 10 seconds: Forced shutdown.
	Locate button and indicator	Blue light blinking: The device is being located. Blinking will stop after 10 minutes.
	Mute button and alarm indicator	Red light blinking with buzzing: There are alarm event(s) exist. <ul style="list-style-type: none"> Warning: Blinking 1 time per second. Serious: Blinking 2 times per second. Emergency: Blinking 4 times per second.
	Ready indicator	Red light solid on: Device is starting up. Green light solid on: Device is ready.

Icon	Name	Description
	HDD indicator	Green light solid on: HDD is operating normally. Red light solid on: HDD(s) are disconnected/abnormal/incompatible.
	Network indicator	Green light solid on: Network operating normally. Red light solid on: Network cable is unplugged / Network interface exception.
	System HDD status indicator	Green light solid on: System HDD is running normally. Red light solid on: Not enough storage space.
	VGA interface	/
	USB interface	Connect to mouse, keyboard or USB flash drive.

1.2.2 Rear panel

The rear panel diagram of the 24-slot device is shown in Figure 1-3, and the interface description can be referred to in Table 1-2.




Figure 1-3 24-Slot Device Rear Panel

Table 1-2 24-Slot Device Rear Panel Interface Description

Number	Name	Number	Name
1	GND	5	RS-232 interface
2	LAN network interface	6	VGA interface
3	USB 3.0	7	Management network interface
4	HDMI interface	8	Power supply

The rear panel illustration of the 36-slot device is shown in Figure 1-4, the rear panel illustration of the 48-slot device is shown in Figure 1-5, and the rear panel illustration of the 60-slot device is shown in Figure 1-6. Refer to Table 1-3 for interface description.




Figure 1-4 36-Slot Device Rear Panel




Figure 1-5 48-Slot Device Rear Panel




Figure 1-6 60-Slot Device Rear Panel

Table 1-3 36-Slot / 48-Slot / 60-Slot Device Rear Panel Interface Description

Number	Name	Number	Name
1	GND	5	VGA interface
2	LAN network interface	6	RS-232 interface
3	USB 3.0	7	Management network interface
4	HDMI interface	8	Power supply

1.3 Installation

This chapter will explain the installation steps for HDDs.

Step 1 Use the key to unlock the panel and remove the front panel chassis.

Step 2 Pull out the side of the front panel with the panel lock at an angle less than 10°, and then slide it horizontally to the left to remove the front panel. Be careful to avoid bending or damaging the golden fingers on the right side of the front panel.

Step 3 Lift the blue spring latch on the hard drive tray to the left to pull out the handle, and then extract the hard drive tray along the guide rails from the chassis.

Step 4 Disassemble the support bracket of the HDD tray.




Figure 1-7 Remove the Hard Drive Tray Bracket

Step 5 Secure the HDD to the tray using 4 screws.




Figure 1-8 Secure the HDD to the Tray

Step 6 Insert the hard drive tray into the chassis following the direction shown in the diagram, and push it fully along the rails until it clicks into right place.




Figure 1-9 Plug in the HDDs

Step 7 Press down the handle to close the blue spring latch, and ensuring the HDDs are properly install and locked.

 **Note**

Repeat Steps 3 to 6 to install additional HDDs.

Step 8 Reattach the front panel and lock it with the key.

Chapter 2 System Configuration

2.1 Login and Activation

Connect the network interface of the notebook to the management network port of the storage device using an Ethernet cable.

Set the IP address of the PC to be in the same subnet as the storage device management network port, with the default management port IP address being 10.254.254.254. For example, set the notebook's IP address to 10.254.254.100 and the subnet mask to 255.255.255.0.

Access the activation interface by using a browser on a laptop to visit <https://10.254.254.254>, and set a login password during activation. After entering the password, activate and enter the system as shown in the following figure.




Figure 2-1 Device Activation

Set a security question for account security after creating a password.

The screenshot displays the 'Account Security Settings' interface. It is divided into three main sections:

- Security Question Configuration:** This section contains three security questions, each with a dropdown menu for the question and a text input field for the answer.
 - Security Question 1:** The question is 'What is your father's name?'.
 - Security Question 2:** The question is 'What is your mother's name?'.
 - Security Question 3:** The question is 'What is the name of your teacher in charge of class in senior high sc...'
- Export GUID File:** This section includes a blue informational note: 'Note: The GUID file is very important which can help you to retrieve your password. It is highly recommended to export and keep the GUID file properly.' Below the note is an 'Export' button.
- Reserved Email:** This section includes another blue informational note: 'Set an e-mail address to receive verification code for password recovery.' Below the note is a text input field labeled 'Reserved Email' with a masked email address (***@***.***). At the bottom of this section is an 'OK' button.

Figure 2-2 Account Security Settings

 **Caution**

Principles your password creation should follow:

- The password should be 8 to 16 characters long. The password should contain at least 2 character types, such as digits, uppercase letters, lowercase letters, and special characters.
 - Do not use risky password:
 - The password should not contain user name, "123" and "admin" (case-insensitive), consecutive increasing or decreasing digits of four or more (such as 1234, 12345, 4321), four or more consecutive identical characters (such as 1111, 8888, "aaaa") and any risky passwords in risky password list.
 - After you log in to the system, if there is no operation within five minutes, for security reasons, the system will log out.
 - After you forget the password, the password can be retrieved by using the device network search (SADP), GUID, answers of security questions and reserved e-mail.
-

2.2 Configuration Wizard

Note

Different series or versions of devices may be equipped with different functions. The actual interface prevails.

After login, the system will automatically perform environment detection and then you will enter the Wizard page, where you can configure the NIC bond, configure time and storage. Operations on the Wizard page are all optional, and you can skip them and configure the corresponding parameters later.

Step 1 View the environment detection result.




Figure 2-3 Environment Detection Passed

Note

Some of the reasons that may cause environment detection failure are as follows: the number of HDDs is less than 6, or there is one or more incompatible HDDs, or HDD capacity is insufficient. Click **Details** for the detailed failure information.

Step 2 If environment detection passed and the current HDD slots are not full, check the maximum and the current number of HDD slots on the device, and click **OK** to enter the wizard configuration page.




Figure 2-4 Check HDD Quantity

Note

HDD slots are not full means the number of HDDs is less than the maximum number of available HDD slots but more than 5.

Step 3 Click **Add NIC Bonding** to configure the NIC bonding, and click **Next**.




Figure 2-5 Add NIC Bonding

Step 4 Set the device time, and click **Next**.

The screenshot shows the 'Wizard' interface for configuring system time. At the top, a progress bar indicates four steps: Network (checked), Time (active), Snapshot, and Storage. The 'General Settings' section contains a notification: 'After you change the area/country/region, the time zone and DST will also be changed.' Below this, the 'Device Time' is displayed as '2025-12-11 10:44:39'. The 'Area/Country' dropdown is set to 'Please select region.' The 'Time Zone' dropdown is set to '(UTC+08:00) Beijing, Chongqing, Hong Kong, Urumqi'. The 'Time Sync Mode' has 'Manual Time Sync' selected. At the bottom, the 'Set Time' field shows '2025-12-11 10:44:16' with a calendar icon and a 'Sync with PC' button.

Figure 2-6 System Time

Step 5 Configure snapshot.

The screenshot shows the 'Wizard' interface for configuring snapshots. The progress bar indicates four steps: Network (checked), Time (checked), Snapshot (active), and Storage. The 'Enable Snapshot Schedule' toggle is turned on. A note states: 'After enabling this function, the device will periodically back up snapshots according to the schedule.' The 'Backup Location' dropdown is set to 'HDD'. The 'Scheduled Cycle' is set to 'Every Month', '10Date', and '18:59:30'. The '* Snapshot Password' field is set to 'Set Scheduled Snapshot Password' with a 'Show/Hide' icon. There is an unchecked checkbox for 'Same as Administrator Password'. The '* Confirm Snapshot Password' field is set to 'Snapshot Password Confirmation' with a 'Show/Hide' icon.

Figure 2-7 Snapshot

Step 6 Configure storage.




Figure 2-8 Configure Storage

Step 6 Click **Completed** in the lower-right corner of the page.

Chapter 3 Service Configuration

Before service configuration, access the system by visiting <http://the IP address of the bound network port> using a web browser and log in.

3.1 Add Channel

Step 1 Click **Channel Management**.

Channel No.	Camera Name	IP Address	Stream ID	Status	Storage Pool	Password S...	Protocol Type	Port	Serial No.	Version	Operation
D1				Online	video	Weak	HIKVISION	20000		V5.5.95 build 210104	
D2				Online	video	Weak	HIKVISION	20000		V5.5.95 build 210104	
D3				Online	video	Weak	HIKVISION	20001		V5.5.95 build 210104	
D5				Online	video	Weak	HIKVISION	8000		V5.4.50 build 250124	

Figure 3-1 Channel List

Step 2 Click **Add**.

Add Channel

[Add Single IP](#)

IP Address*

Protocol: Protocol M... Port*:

User Name: Password:


Transfer Protocol:

Figure 3-2 Add Channel

Step 3 Enter the IP address of the channel.


Step 4 Click **Test** to check connectivity.

Step 5 Set the following parameters.

- **Protocol:** Select from the drop-down list or set a custom protocol. For details about customizing protocols.
- **User Name & Password:** Set for later channel management.
- **Port:** Port of the channel. It is 8,000 by default and you can edit the port number. After editing, you can click  to set the port number to the default value.
- **Transfer Protocol:** Data transmission protocol. Select **Auto**, **TCP** or **UDP**.

Step 6 Click **Confirm** to finish adding the channel, or click **Continue to Add** to add the channel and continue to add the next channel.

Step 7 (Optional) Perform the following after adding channels.

- **Edit Channel:** Click the camera name to enter the **Edit Channel** page and edit parameters.
- **Export Channels:** Click **Export** to export information of all channels to your local PC. Select channel(s) and click **Export** to export information of the selected channel(s) to your local PC.
- **Import Channels:** After exporting channels, enter channel information in the exported file. Click **Import**, and click  to batch import channels.

3.2 Configure Storage Pool

This section includes basic operations for storage pools: adding, editing, deleting, and adjusting storage pool space. After adding a storage pool, it is necessary to associate channels with the storage pool.

3.2.1 Add Storage Pool

Step 1 Click **Storage Management** → **Storage Pool** → **Storage Pool**.

Step 2 Click **Add**.

Figure 3-3 Add Storage Pool

Step 3 Configure storage pool parameters.

- **Type:** Select **Recording Pool** or **Picture Pool**.
- **Storage Space:** Enter the storage space. You can click **Tool for Estimating Recording Duration** to calculate the estimated storage space or recording period.
- **Overwrite:** Enable this function to allow overwriting of the oldest recording when storage space is insufficient. Disable this function to stop recording when storage space is insufficient.
- **Video Expired Time:** When **Custom** is selected, recordings will be stored according to the configured recording cycle. Expired recordings will be cleared and cannot be recovered.

 **Note**

You can add up to 8 storage pools.

Step 4 Click **Confirm**.

3.2.2 Edit/Delete Storage Pool

Step 1 Click **Storage Management** → **Storage Pool** → **Storage Pool**.

Step 2 Hover around the card of the storage pool, and then click **Edit** or **Delete**.

Step 3 Edit or delete the storage pool.

Step 4 Click **Confirm** to complete the operation.

 **Caution**

After you delete the recording pool, the linked channel(s) of this recording pool will become unable to record. Link to another storage pool promptly.

3.2.3 Adjust Storage Pool Space

Step 1 Click **Storage Management** → **Storage Pool** → **Storage Pool**.

Step 2 Click **Adjust Storage Pool Space**.

Step 3 Adjust storage pool space as needed.

- **Enter Remaining Quantity:** Allocate all the remaining capacity to the storage pool.
- **Tool for Estimating Recording Duration:** Calculate the estimated storage space or recording period.




Figure 3-4 Adjust Storage Pool Space



3.2.4 Link Channel


Supports the configuration of channels associated with storage pools.


Step 1 Click **Storage Management** → **Storage Pool** → **Storage Pool**.

Step 2 Click a storage pool in the list.

Step 3 Configure linked channel(s) for the storage pool as needed.

-  **Linked Channel** : Add linked channel.
-  **Move To** : Move the checked channel(s) to another storage pool.

Step 1  **Unlink Channel** : Batch remove the checked channel(s) from the current storage pool.

-  : Search the linked channel(s) by channel name.

3.3 Configure Recording Schedule

Step 1 Click **Storage Management** → **Recording Schedule**.




Figure 3-5 Recording Schedule

Step 2 Turn on the switch in the **Enable** column.

 **Note**

For channels added to the device, the switch is disabled by default.

Step 3 Set the recording schedule as **All-Day Continuous Schedule**, **All-Day Event Schedule**, or **Custom**.

Step 4 (Optional) When selecting **Custom**, set the schedule details on the right side.




Figure 3-6 Custom Schedule Details

- 1) Select a schedule type, including **Continuous**, **Event** and **Motion Detection**. Drag the mouse to set the schedule period.
- 2) (Optional) Select **Erase** and then drag the mouse to cancel the schedule you have drawn.
- 3) (Optional) Hover around the time table to adjust the schedule at minute level.
- 4) Click **Save** to apply the schedule.
- 5) (Optional) Click **Copy To...**, you can copy the schedule to other channels.

Step 5 Click  in the **Advanced Configuration** column to set the corresponding parameters.

Advanced Configuration [X]

ANR ⓘ

Pre-Record ⓘ
Not Pre-Record ▾

Record Delay
5sec ▾

Stream Type
Main Stream ▾

Link Storage Pool
video

Video Expired Time
10day(s)

Please go to Storage Pool to configure the recording cycle settings.

[Configure](#)

Save

Figure 3-7 Advanced Configuration

- **ANR:** Asynchronous Node Recovery (ANR) is a fault tolerance mechanism. When it is enabled, if there is a network anomaly between the device and the camera, the camera will be used for recording storage temporarily (provided that the camera is equipped with storage media). Once the network is restored, the stored data will automatically synchronize to the device, ensuring the integrity of the recordings.
- **Pre-Record:** Record before the alarm.
- **Record Delay:** Record after the alarm.
- **Stream Type:** Supports main stream and sub stream.

 **Note**

- Actual pre-record time may be shorter than the setting.
- After reaching the recording cycle, the outdated recordings will be deleted.
- For detailed recording cycle settings, click **Configure** to go to storage pool page.

3.4 Live View

Supports live view of channel video, and you can select the pane for the live view channel.












Figure 3-8 Live View

- In the live view interface, you can preview images, record videos, and capture pictures.
- The split screen mode supports 1, 4, 9, and 16.
- Detailed function key introduction is shown in the following table.

Table 3-1 Live View Interface Function Buttons

Button	Function Description
	Start All Live View / Stop All Live View
	Previous/Next Page The button is only available after starting all live view.
	Mute/Volume Adjustment
	Electronic Amplification. After enabling, use the mouse scroll wheel to zoom in or out of the live view.
	Capture
	Split Screen
	Start All Recording
	Live View Ratio Supports 4:3, 16:9, Original Ratio, and Auto.
	Full-Screen



See Far, Go Further

UD45993B