



Instruction Manual

IS37



Works with
Apple Find My

Use of the Works with Apple badge means that a product has been designed to work specifically with the technology identified in the badge and has been certified by the product manufacturer to meet Apple Find My network product specifications and requirements. Apple is not responsible for the operation of this device or use of this product or its compliance with safety and regulatory standards.


Apple, Apple Find My, Apple Watch, Find My, iPhone, iPad. iPadOS, Mac, macOS and watchOS are the trademarks of Apple Inc. IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.

Device Button Instructions

1.Power on

After installing the battery:

- **Press and hold the button for 5 seconds.**
- The device will **beep**, and the light will **flash 3 times**, indicating it has powered on.



2.Check device status

- **Double click the button.**
- If the device **beeps and flashes 3 times**, it is powered on and working.
- If there is no response, it is off. **Press and hold the button for 5 seconds** to power it on.

3.Lookup the S/N Broadcast

- Locate the button on the front top of the IS37.
- Quickly press the device button six times.
- Six confirmation beeps will sound and the light will blink six times.

4.Re-Enter Pairing Mode

After removing device from the app:

- The device **beeps** and the light **flashes 6 times**, entering **pairing mode**.
- If not paired within 10 minutes, it exits pairing mode.
- To re-enter pairing mode, **click the button once**. The device will **beep and flash once**.

5.Factory Reset

Remove the device from the **Find My** app.

With the device powered on:

- **Double-click the button** (the device will beep)
- Then **press and hold** the button for **8 seconds** until it **beeps again** and the light **flashes 3 times**
- **Release the button**. The reset is complete, and the device can now be paired again.

6. Power Off

While the device is on:

- **Press the button 5 times within 2 seconds**
- The device will **beep**, the light will **flash 3 times**, and it will power off.

Battery Replacement Instructions

1. Use a screwdriver to **loosen the screws** on the back (turn anticlockwise)
2. Use a thin tool to carefully **open the outer shell**.
3. Remove the old battery. Install a **new CR2032 button battery**, positive side facing up.
4. Reassemble the back cover and **tighten the screws**.
5. **Press and hold** the button for 5 seconds to turn the device back on.

FAQs

How do I confirm if the device is turned on?

1. **Double-click the button**. If the device **beeps and flashes 3 times**, it is on.
2. If not, **press and hold for 5 seconds** to turn it on.

What if pairing fails?

Check your internet connection and try:

1. Switching networks (Wi-Fi ↔ Mobile Data).
2. Factory resetting the device (see above).

Regulatory Safety Information



**WARNING: KEEP BATTERIES OUT
OF REACH OF CHILDREN**

Swallowing may lead to serious injury in as little as 2 hours or death, due to chemical burns and potential perforation of the oesophagus. If you suspect your child has swallowed or inserted a button battery, **seek immediate medical attention.**

Poison control centres:

Region	Contact Number
Australia	13 11 26
Canada (ON)	1-800-268-9017
Canada (BC)	1-800-567-8911
Canada (QC)	1-800-463-5060
USA	800-498-8666

Emergency contact for poisoning in UK:

Call 111 (NHS non-emergency number)

- Available 24/7 for urgent medical help (including suspected poisoning)

In a life-threatening emergency call 999

Rated voltage 3V

Rated current ~15mA

Immediately dispose of used batteries and keep away from children.

DO NOT dispose of old batteries in household waste. Even used batteries can cause severe injury or death.

DO NOT use if the compartment is not secure.

Dispose of used button batteries promptly and safely. Flat batteries can still be dangerous.

European Union-Disposal Information:



The symbol above means that according to local laws and regulations your product and/or its battery shall be disposed of separately from household waste. When this product reaches its end of life, take it to a collection point designated by local authorities. The separate collection and recycling of your product and/or its battery at the time of disposal will help conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment.

Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. **DO NOT** dispose of batteries in household waste or incinerate.

Even used batteries may cause severe injury or death.

Seek immediate medical advice for treatment information.

Battery type: CR2032

Nominal battery voltage: 3V

Non-rechargeable batteries are not to be recharged.

DO NOT force discharge, recharge, disassemble, heat above 60°C or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns.

Ensure the batteries are installed correctly according to polarity (+ and -).

Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.

Always completely secure the battery compartment. If the battery compartment does not close securely, stop using the product, remove the batteries, and keep them away from children

Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc, or rechargeable batteries. Risk of fire and burns. DO NOT recharge, disassemble, heat (-20°C + 70°C) or incinerate.

Article 12

Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristics and functions of the original design of the certified lower power frequency electric machinery.

Article 14

The application of low power frequency electric machineries shall not affect the navigation safety nor interfere a legal communication, if an interference is found, the service will be suspended until improvement is made and the interference no longer exists. The foregoing legal communication refers to the wireless telecommunication operated according to the telecommunications laws and regulations. The low power frequency electric machinery should be able to tolerate the interference of the electric wave radiation electric machineries and equipment for legal communications or industrial and scientific applications.

Safety Statement

FCC Caution. This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions: (1) This device may

not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired

operation. Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no

guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television

reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help. This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your
- body.

FCC ID: 2ADD5-F20X

Important tips:

When pairing a device with Find My app, the phone will link to the Apple server. Pairing may fail because of network problems. The following actions are recommended:

1. Change the phone's network, such as switching between Wi-Fi and mobile network.
2. Factory Reset for the device:

When the device is powered on, double-click the device button. The device will beep, then immediately long press the device button for eight seconds until the device beeps for the second time and the indicator light flashes. Release the button. Factory Reset is completed. (Note: after long pressing the device button for 2 seconds, the device will and the indicator light near the button flashes. Do not release it. Continue to press and hold the button until the device emits a sound for the second time, and the indicator light flashes. Release the button).

3. Pair with Find My app.

Product overview

Battery compartment screws

